




TOUCH TD1100 65/90 – Configuration de base KB 20140225




Restore Custom Default Configuration




Enter/Exit Programming Mode




Set Global Suffix




0




0



Enter/Exit Programming Mode



Country Mode = France



Enter/Exit Programming Mode